

Subaru Preventive Maintenance Program (SPMP)

Enjoy Great Savings ! with our most popular Subaru Maintenance Package

For **2 Years** or **40,000km** [Whichever comes first]

Program entitles Customer to 4 Services at Intervals of 6 Months or 10,000km,
commencement from first intake

[All Labour, Parts & Lubricants Included In Package**]



Subaru Preventive Maintenance Program

This program is specially packaged to cater for all Subaru Owners. It ensures your vehicle is maintained in the most economical and comprehensive manner, in accordance with Manufacturer's recommended Preventive Maintenance Schedule & Parts Replacement interval.

Competitive Pricing

We offer very competitive rates well below normal price. No need to worry about a sharp inflationary increases in price of Labour, Parts and Lubricants. Your cost of ownership will be at its minimum.

5% discount for 2nd sign up

10% discount for 3rd sign up onwards

Value Added Quality Service

At Motor Image, we ensure all maintenance services are carried out in accordance with Manufacturer's Standard [Subaru Corporation] & Quality. With the latest state of art equipment and well trained technicians, you will have "Peace Of Mind" driving your Subaru.

Labour, Spare Parts & Lubricants Charges**

There will be no hidden charges. All Labour, Spare Parts & Lubricants are included in the SPMP Package. High quality Fully Synthetic Engine Oil will be used for all services.

Service Intervals

Service Interval shall be 6 months or mileage cover of 10,000km, whichever occurs earlier starting from the date of program commencement.

Transferability & Refund

The Program is transferable to the subsequent owner of the same vehicle (Subject to proper authorization), adding value to a potential resale of vehicle. **No refund shall be granted** in the event of program termination. However, it can be transferred to a New Subaru should the customer decide to replace his old vehicle. [Additional Rate applies if new vehicle has higher capacity or belongs to a higher category]

Price as per engine capacity (GST inclusive)

1,600cc & Below	\$1,421
1,601cc to 2,000cc	\$1,533
2,001cc to 2,500cc	\$1,615
3,000cc & Above	\$1,680

** Lubricants & Parts Replacement shall be fixed as per scheduled replacement indicated overleaf & in accordance with replacement interval or upon reaching wear limit. Any other repairs, labour or material usage not listed in the program items overleaf will be chargeable to customer.

All Terms & Conditions as stated in SPMP Agreement shall apply in conjunction with our "General Terms & Conditions of Service".

Enjoy The Smooth Performance Of A Well Maintained Subaru!

Maintenance Package Categories			Please follow this sequence	B	A	C	A
			Mileage in KM ('000)	20k	30k	40k	50k
				60k	70k	80k	90k
				100k	110k	120k	130k
Description of Job & Maintenance Items							
Change	<input type="checkbox"/>	Engine oil; oil filter (Subaru Fully Synthetic Engine Oil)		○	○	○	○
Clean	<input type="checkbox"/>	Air cleaner element; engine compartment		○	○	○	○
Check & top up for level							
	<input type="checkbox"/>	Brake fluid		○	○	○	○
	<input type="checkbox"/>	Auto / manual transmission; transaxle / differential oil		○	○	○	○
	<input type="checkbox"/>	Power steering fluid; engine coolant; washer tank water; battery distilled water		○	○	○	○
Check							
	<input type="checkbox"/>	External lighting system		○	○	○	○
	<input type="checkbox"/>	Tyre pressure including spare tyre [Puncture repairs - additional charges]		○	○	○	○
	<input type="checkbox"/>	Wiper washer		○	○	○	○
Clean & Lubricate							
	<input type="checkbox"/>	Door hinges, locks catches, battery terminals		○	○	○	○
Clean & Adjust							
	<input type="checkbox"/>	Clutch / cable freeplay (if applicable)		○	○	○	○
Engine							
	<input type="checkbox"/>	Electronic tuning by diagnostic inspection		○	○	○	○
	<input type="checkbox"/>	Pressure test cooling system		○	○	○	○
	<input type="checkbox"/>	Spark plug inspection [Except platinum plugs]		○	○	○	○
	<input type="checkbox"/>	Inspect all vacuum hoses		○	○	○	○
	<input type="checkbox"/>	Inspect O ² sensor and CO level		○	○	○	○
	<input type="checkbox"/>	Adjust idling speed and ignition timing [Conventional type]		○	○	○	○
Check							
	<input type="checkbox"/>	Air conditioning system / cool efficiency / clean filter		○		○	
	<input type="checkbox"/>	Radiator hoses condition / water pump / fan condition		○	○	○	○
	<input type="checkbox"/>	Battery condition		○	○	○	○
	<input type="checkbox"/>	Power steering, pipes & hoses		○	○	○	○
	<input type="checkbox"/>	Fuel pipes & hoses		○	○	○	○
	<input type="checkbox"/>	All engine / transmission mountings		○	○	○	○
	<input type="checkbox"/>	Drive shaft dust covers / rack & pinion dust cover		○	○	○	○
	<input type="checkbox"/>	Seat belt operation		○	○	○	○
Brake System							
	<input type="checkbox"/>	Check & service all 4 wheel brakes / repack wheel bearing grease (if necessary)		○		○	
	<input type="checkbox"/>	Check all brake disc rotors & drum condition [Disc replacement - additional parts charges]		○		○	
	<input type="checkbox"/>	Check all brake calipers		○		○	
	<input type="checkbox"/>	Check rear wheel cylinders		○		○	
	<input type="checkbox"/>	Check brake master pump		○		○	
	<input type="checkbox"/>	Adjust handbrake		○		○	
	<input type="checkbox"/>	Check brake pads thickness		○	○	○	○
	<input type="checkbox"/>	Check brake shoe thickness		○	○	○	○
Tyres							
	<input type="checkbox"/>	Rotate / balance front tyres		○	○	○	○
	<input type="checkbox"/>	Check all tyres conditions / wear including spare tyre		○	○	○	○
Replace if necessary (subject to Subaru's specifications & wear limit)							
	<input type="checkbox"/>	** Front brake pads [Wear limited: 2mm]		○○	○○	○○	○○
	<input type="checkbox"/>	** Rear brake pads / brake shoes [Wear limited: 1.5mm]		○○	○○	○○	○○
	<input type="checkbox"/>	** All drive belting [Tensioner & pulley - additional parts charges]		○○	○○	○○	○○
	<input type="checkbox"/>	Normal Bulb for headlamp / side lamp / indicator lamp / room lamp - renew when blown [Exclude xenon bulbs, LED brake & head light, fog lamp, 3rd brake light & meter lights. Any replacement - additional parts charges]		○	○	○	○
Replace							
	<input type="checkbox"/>	** Spark plugs [Platinum or iridium plug, replace at 100,000km]		○		○	
	<input type="checkbox"/>	Air cleaner element				○	
	<input type="checkbox"/>	Fuel strainer [Not applicable to in-tank strainer]		○		○	
	<input type="checkbox"/>	Front wiper refill [Exclude rear wiper - additional parts charges]		○		○	
Replace oil / fluid / coolant							
	<input type="checkbox"/>	CVT Fluid - Replace at 50K interval for all CVT models [Use generic Subaru CVT fluid]		○			○
	<input type="checkbox"/>	ATF (Automatic Transmission Fluid) / manual transmission / transaxle / axle / differential oil				○	
	<input type="checkbox"/>	Brake fluid [Replace every 20K]		○		○	
	<input type="checkbox"/>	Coolant [Replace every 100K]		○		○	

** As per Subaru Specification
Package item subject to changes and shall supercede any maintenance items in previous Subaru Preventive Maintenance Programme
Exclusion: Any other repairs, labour and material usage not stated in this brochure are excluded from the “Subaru Preventive Maintenance Programme” and will be chargeable to customer